
O
N
M
L
K
J
I
H
MD BLOCK
HP101 PLAYBACK HEAD
SWITCH BOARD
MUTE BOARD
CNP402 7P
CNP401 8P
IC301 EQ AMP
IC302 DOLBY AMP
IC303 AMS
IC304 MAIN/AUX SELECTOR
IC410 MIX/TONE AMP
IC310 MIX/TONE AMP
IC202 EEP ROM
IC201 SYSTEM CONTROL
Q301,401 NOR/MTL SW
Q453,454 AMS PLUNGER DRIVE
DOLBY LEVEL
DOLBY-ON/OFF
L.CH-OUT
R.CH-OUT
P-ON8.5V
AUDIO-GND
POWER-ON8.5V
MUTE
PACK-IN